

## ***MICROH - LED Chameleon V2*** **DMX Channel Allocation**

### **Mode 1 – 3 Channels:**

Channel 1: 0-255 RED 0% - 100%  
Channel 2: 0-255 GREEN 0% - 100%  
Channel 3: 0-255 BLUE 0% - 100%

### **Mode 2 – 4 Channels:**

Channel 1: 0-255 DIMMER 0% - 100%  
Channel 2: 0-255 RED 0% - 100%  
Channel 3: 0-255 GREEN 0% - 100%  
Channel 4: 0-255 BLUE 0% - 100%

### **Mode 3 – 6 Channels:**

Channel 1: 0-255 DIMMER 0% - 100%  
Channel 2: 0-255 RED 0% - 100%  
Channel 3: 0-255 GREEN 0% - 100%  
Channel 4: 0-255 BLUE 0% - 100%  
Channel 5: STROBE  
    000-009 No Function  
    010-057 Strobe - Slow to Fast  
    058-059 No Function  
    060-108 Strobe - Slow to Fast  
    109-110 No Function  
    111-159 Strobe Fast  
    160-161 No Function  
    162-255 Random Strobe  
Channel 6: MACROS  
    000-009 No Macro  
    010-050 Colour Fade  
    051-091 Colour Fade RGB Only  
    092-132 Colour Fade  
    133-173 Colour Snap  
    174-214 Colour Pulse  
    215-255 Random all Macros